

Proprietary Information


The information in this guide is intended to be used as a reference to parts and their locations to aid the owner, operator, and mechanics using this piece of equipment. This document in any form is not to be copied, sold, or used as an engineering document to construct, modify, or design any such equipment. All information and drawings herein belong exclusively to Curry Supply Company and may not be duplicated in any way without prior written consent from Curry Supply Company.

Disclaimer

The information in this guide may not reflect the full configuration of your vehicle. The parts displayed are for general reference and any "custom" additions may not be fully shown.

Curry Supply Company is a ISO9001 compliant company. Below you will find all the revisions pertaining to this document.

REVISION NUMBER	INITIALS	CHANGES	DATE
1	MLC	UPDATED VISUALS. NO CHANGES TO INFORMATION	02/19
2	MLC	UPDATED VISUALS AND INFORMATION.	11/19



ON ROAD WATER

OPERATIONS GUIDE

DOCUMENT NUMBER 140-002o

STOP!
You must read this document before attempting to operate this vehicle. Failure to do so may void your warranty and can result in serious injury or death.

PARTS
800.567.5127

WARRANTY/SERVICE
800.345.2829

1624 Curryville Road, Martinsburg, PA 16662
800.345.2829 · CurrySupply.com